

1. Preparing the Tablet

Fully charge your *Tablet* and familiarize yourself with its features. Configure the tablet interface as desired.

2. Getting the PT900 Android APP

Get the PT900 APP from one of the following:

- Google Play Store (free download):
 Set up a free account in Google Play
 Store. Search for the TransPort PT900
 APP and install it on your tablet.
- QR Code or BH Website (free download):

Either Scan the QR Code below or go to

"https://www.industrial.ai/download-c enter" to download the PT900 APP from the website to your tablet.



• SD card included with your PT900:

Plug the SD card directly into your tablet, and select the APK file from the SD folder.

Note: Check the Panametrics website for the latest version.

TransPort[®] PT900 APP Installation Guide

3. Installing the PT900 APP

If the PT900 APP was obtained from the SD card or from the QR Code/website, install the APP as follows:

 a. Open the "My Files" folder on the tablet screen and select the APP from the SD folder.



 b. Enable the security option to allow the installation of software from "Unknown sources" for this installation only.



c. Click on the APK file, and you will see the screen below. Click "Install" to begin the installation.



1100 Technology Park Drive, Billerica, MA 01821, U.S.A. Telephone: 978-437-1000 or 800-833-9438

Sensing House, Shannon Free Zone East, Shannon, County Clare, Ireland, Telephone: +353 61 470200

SWD/916-147/000/00

916-147, Rev. B